

EXPERIENCE
THE MAGIC OF
PREMIUM
PRODUCE
PROTECTION

MaTri TABLETS

Instructions for Use

1. PREPARATION

- Make sure you have the right size and number of MaTri Tablets for the treatment. Refer to your DoseRight calculation or order details.
(Selection of tablet size and quantity is based on the volume of the treatment area. Calculate the treatment area volume by multiplying its length, width, and height, then divide the total number by the rate specified on the label.)
- Ensure airtight storage: The storage room or container must be well-sealed and airtight to maintain effective concentration of 1-MCP gas.
- Monitor temperature and humidity: The room should be at the recommended temperature (usually between 0–5°C or 32–41°F) and relative humidity (around 90–95%).
- Remove ethylene sources: Do not store treated produce with ethylene-producing fruits (like bananas or avocados) during treatment.



2. PRODUCT HANDLING

- MaTri Tablets comes in water-resistant, sealed aluminized pouches. Open the pouch and remove the required number of tablets. MaTri Tablets are effervescent tablets that dissolve in water.
- Protective gear: It is recommended that gloves be worn when handling this product. Avoid direct inhalation or contact with the pouch contents. See instructions on the label for additional safety guidelines.
- Store in a cool, dry place away from heat and humidity. Use the entire package at once. If not possible, reseal and store briefly after opening, keeping away from humidity.

Place an order
on ma-tri.com

...or contact us!

Keith Culver
+1 585 738 2189
keith.culver@freshinset.com

Gordon Robertson
+1 661 487 2230
gordon.robertson@freshinset.com

3. APPLICATION

- Ensure that the treatment area is properly and promptly sealed.
- Place on a stable surface: bucket, tray or the MaTri generator following the use instructions.
- Open the pouch containing the MaTri Tablets and drop the appropriate number of tablets into bucket or tray filled with recommended amount of water. **DO NOT CUT THE TABLETS.**
- The tablets will take 1-3 minutes to begin dissolving and releasing 1-MCP.
- Leave the storage area, seal the door, and post the warning sign.
- Keep the room sealed for 12–24 hours (as per label instructions). Do not enter during this period.



4. USE MaTri SURE TEST

- Hang the MaTri Sure strip on bin or box.
- After treatment, change in the color plate from pink to any visible yellow indicates a successful application in real-time.



5. POST-TREATMENT

- After treatment, ventilate the room before re-entry.
- Resume normal storage practices.
- Repeat treatments only as recommended (usually unnecessary unless long-term storage is extended or fruit is re-exposed to ethylene).
- Discard remaining post-treatment liquid from bucket/tray into the sewer.

